

Universal iSmartphone X-SIM

How to unlock and use this sim unlock card:

1. Prepare your SIM card, turbo SIM and pen knife.
2. Cut your SIM card according to the turbo SIM IC chip.
3. Place your SIM card together with turbo SIM and put in to your mobile phone. Now your mobile phone is unlocked.

The mobile phone models can be unlocked now:

Alcatel	Samsung	SonyEricsson	Nokia
OT201	F851	K300	N76
OT801	F256	W660I	
C550	F252	W810I	6500c
E11e N1	F151	K700	6630
OT201	C550	T630	3500c
Blackberry	811SH	K310	N70
8820	816SH	Z310	6110navigator
8800	904SH	P990I	5610
8100	SH9051	K770	N95
8700	812SH	K510	6500s
7100	813SH	K508	N72
8120	920SH	K500	
8130	SH9041	W200	5310
8300	815SH	V630	
8310	804SH	P1	
8310	G900	K800	2630
8320	TS705	K550	N82
7130c	702IG	J220	6288
7130g	950IU	W300i	6070
8707v	920P	W580	6161
7290	D600E	10510	3250
Huawei	F600	K800	1208

120	P910	K810	1600
MT810	i600	S500	6125
T7200	Z170	W910	2310
T2000	Z240	W660	6822
T868	J600	P990	E60
T5700	SC707	u630	6080
C2800	F900	u600	6120c
C2606	Z370	k618	
C2860	C260	t230	6310i
LG	X640	k850	N95 8GB
KU890	X480	w900	E90
KU990	C450	w810	6500
KG800i-chocolate	U700	J100	6280
U310	L760	T610	5200
U880	U600	P960	N73
KU250	X150	W960	6120
U250	J400	SPV	6300
KG130	E420	M650	3110
B2050	A411	300	6301
KG275	705	Toshiba	7500
U300	706	811T	5500
KE850	707	812T	6230
KE9709(G70)	708	813T	N93
U890	709	904T	N93i
KG800	E420	902T	6136
KU580	A411	803T	N81
CU720	Z170	911T	N80
Siemens	2370	G500	7373
A38	X640	G900	7370
C65	L760	TS705	6233
A50	i600	810T	5300
S68	x480	TS705	5070

Sagem	Sharp	T-mobile	
x2-2m	705H	Sidekiek	6310i
600x	810SH	sidekiekII	7390
700x	816SH	sidekickIII	Japan phones
my-150x	904SH	Vodafone	705Px
my-220x	SH905I	U715	Va10P
my x6-2	812SH	810	V820p
W8	813SH	Motorola	V911T
Japanese DOCOMO	920SH	V600	P905I
P905I	SH904i	A780	709sc
D905I	815SH	V8	920se
SO905I	804SH	V547	V810p
SO905ICS	G921SH	V3i	V820p
F905I	922SH	Z8	920p
N905I	903SH	W510	705px
Japanese SOFTBANK	550SH	V3	V811T
920SH	770SH	Z6	V812T
920SC	Gx15	V575	V911T
904SH	GX25	Lobster	V920T
SH905I	ZTE	485	V70T
921SH	F150	25 MDA Compact III	L600i
922SH		26 MODEM OPTION ICON 225	L602i
705SH			D905i
903SH			F905i
550SH			S0905i
770SH			S090iec
GX15			Sh905i
GX25			D906i
GX20			P906i
			So906i
			F906i
			SH906i